BPW Axle & Suspension

First Service Inspection AL II with 70mm Trailing Arm




To be performed within the first 2500 km.


DATE:		BUILDER: DOMETT	
OPERATOR: TALLE	45	REG. NO(s)	
TYPE (circle)	Dog / Semi / Tri / Quad	KMS:	
Flat deck / Curtainsider	/ Tipper / Tanker / Other	Hubo Serial No(s):	
		V.I.N Number	
AXLE SERIAL NUMBER(S): 1st: 113849003 2nd: 113849042 3rd: 11 3849084			
(located on axle ID tag, see picture overleaf)	4th:	5th: 6th:	
SUSPENSION SERIAL N	UMBER(S): Front: TE	Rear: TE >>66	
ITEM	CHECK		✓
Signatus (Signatus)			
1. U-Bolts	Re torque - 550 Nm		
	· · · · · · · · · · · · · · · · · · ·	ICAL FOR THE SERVICE LIFE	
	OF THE SUSPENSION		
2. Pneumatic system		pneumatic system and that it	
z. i noamano oyotom	is piped correctly (refer assembly instructions)		
	1 ' '	,	
3. Ride height valve	Check for air leaks and rectify if necessary. Check linkage arrangement (see diagram over page) Ensure trailer air supply is connected and brakes are released.		
o. Mae neight valve			
	1		mm
4. Spring eye bolt	Check ride height is at manufacturers recommendation and record. mm Re torque - with 30mm bolts (46mm hex size) 990 Nm Re torque - with 24mm bolts (36mm hex size) 650 Nm		
4. Spring eye bolt			
	1	· ·	
5. Shock absorber	(when suspension is at correct ride height)		
5. Shock absorber	Re torque - 420 Nm	Had	
6. Air bags	Check Webbing Sling is installed correctly (see diagram over page)		
o. All bags	Re torque airbag fastener	SS Non	
	Upper lid	66 Nm	
y vers of the second of the	Lower lid	230 Nm	
			A COLOR
7. Hub Bearing	Check for hub bearing play. Adjust if necessary.		
B. Check Wheel Nuts 9. Brakes - Drum	Check wheel nut torques: 640 Nm Check brake adjustment. Adjust if necessary.		
5. Diakes - Diulli			
	Check slack adjuster return springs are in place		
10. Brakes - Disc		in place. (see maintenance manual)	
	Check all Bottom Bungs ar	e removed from Brake Chambers	
DEFECTS / REMARKS / A	ACTION		
COMPLETED BY (MECHANIC)		NAME OF FIRM	
SUDEDVISED BY (EODEMAN)		ADDRESS	

Fax completed form to BPW Transport Efficiency (NZ) on 09 273 8086.

Axle ID Tag



Removal of brake chamber bungs



Webbing sling installation

Rubber Ring Retainer Part No. AS-0002 Webbing Sling Refer Suspension Assembly Drawing for the required length Position the webbing sling wear pads over the ends of the shock absorber. Shock Absorber Catchstrap Retainer Part No. AS-0001 Lock Nut M24 Part No. 02.5220.74.12

Ride Height Measurement Centre of axle to underside of chassis

